A4 Flip File Displays

Website Ref: UKP16A4

Supplied:

1x Metal Wall Bracket 10x A4 Black Posting Sleeves

Overall Measurements:

Wall Bracket

Length = 355mm Width = 80mm See - Wall Bracket Image >>>>>

Poster Sleeves

Length (Metal Edges) = 355mm Length (Poster Sleeve) = 325mm Width (Poster Sleeve) = 230mm Opening (Poster Sleeve) = 10mm

Weight:

Overall 1kg (approx)

Designed for:


A4 Portrait Documents
Length = 297mm
Width = 210mm
Double-sided Sleeves - Hence hold 20x A4's

Finer Details:

- 1. Decide where you want to attach the metal bracket
- 2. Place the bracket against the wall and level it (use a spirit level)
- 3. Whilst holding the bracket to the wall, pencil mark the hole locations
- 4. Now secure the metal bracket using supplied raw plugs and screws
- 5. Now simply push the sleeve top metal section into the top 1st hole of the bracket
- 6. Now slightly bend the bottom metal section and insert into the 1st hole of the bracket
- 7. Repeat steps 5 and 6 for all remaining sleeves Finally start adding your documents!

A4 "Black" Flip File Displays (10x Pockets)







Wall Bracket



Poster Sleeve (notice the metal ends!)










Supplied:

A Standard Order Comes With = 1x Bracket and 10x Sleeves

Extending:

If you want to extend the display and have a seamless run, then this is also possible Just order as many as you want, once delivered....

Push these into the rear of the brackets then, secure to the brackets onto the wall When completed the brackets but-together for a seamless run!





Check that you have 10x Sleeves!



Metal top section has now been inserted



Metal bottom section is now inserted

Sleeves with Metal Top and Bottom Pins

Metal pins help hold the sleeve onto the bracket Metal pins also create max flexibility for adding and removing as necessary

Adding the Sleeves into the Bracket

- 1. Firstly Make sure the opening on the sleeve is top most
- 2. Secondly present the top metal pin into the top of the bracket
- 3. Thirdly present the bottom metal pin into the bottom of the bracket (bend slightly)
- 4. Keep repeating steps 1,2 and 3 until all sleeves are added
- 5. Finally, now add your documents + when documents are out of date, simple swop them!

